

Oceanic Teak Furniture Adirondack Chair Assembly

There are just 4 parts – Seat / Back / 2 x Arms (Left & Right) Plus 6 Brass Bolts, 4 Brass Screws & 1 Allen Wrench

Tools required – Wooden or Rubber Mallet

You will see there are coded stickers on the parts, make sure you align the relevant stickers to ensure the furniture is assembled correctly.

You may need to use a wooden or rubber mallet to tap the sections into place and ensure they are slotted together securely.

1. Lay seat section flat on its bottom.
2. Place the seat back section making sure any stickers are correctly lined up.
3. Insert the brass screws into the relevant holes on each side and hand tighten
4. Place these sections on their side and place the relevant arm/leg section into position and using the brass bolts to secure in place, hand tighten them at this point.
5. Turn the whole chair onto the other side. Place the remaining arm section on top, lining up the holes and using the bolts to secure into position.
6. Carefully rotate the seat and stand onto its legs – You may need help at this point – Make sure the parts are still securely in place.
7. Fully tighten all bolts and screws.

