

## Oceanic Teak Furniture Java Oval Armchair Assembly

There are just 6 parts – Seat / Back / 2 x Arms (Left & Right) / Front seat brace / Back seat brace Plus 8 Brass Bolts, 4 x Screws & 1 Allen Wrench.

Tools required – Wooden or Rubber Mallet / Phillips Head Screwdriver

You will see there are coded stickers on the parts, make sure you align the relevant stickers to ensure the furniture is assembled correctly.

You may need to use a wooden or rubber mallet to tap the sections into place and ensure they are slotted together securely.

1. Lay one arm section on its side with the holes facing up.
2. Insert the back section making sure any stickers are lined up and ensuring it is slotted fully and securely into place
3. Insert the back seat brace making sure any stickers are lined up and ensuring it is slotted securely & fully into place
4. Insert the seat section lining up any stickers and ensuring it slots into place.
5. Insert the front seat brace making sure any stickers are lined up and ensuring it is slotted securely & fully into place.
6. Place the remaining arm section on top, lining up the holes and tap securely & fully into place.
7. Carefully rotate the bench and stand on its legs – You may need help at this point – Make sure the parts are still securely & fully in place.
8. Insert the brass bolts into the relevant holes on each side and hand tighten, then using the Allen wrench fully tighten each bolt.
9. Lay the bench over onto its back and screw the 4 screws through the pre-drilled holes (2 on each side) in the seat section and into the arm sections.

