

Oceanic Teak Furniture Rocking Chair Assembly

There are just 4 parts – Seat / Back / 2 x Arms (Left & Right) Plus 6 Bolts & 1 x Allen Wrench

Tools required – Wooden or Rubber Mallet

You will see there are coded stickers on the parts, make sure you align the relevant stickers to make sure the furniture is assembled correctly.
You may need to use a wooden or rubber mallet to tap the sections into place and ensure they are slotted together securely.

1. Lay one arm section on its side with the holes facing up.
2. Insert the back section making sure any stickers are lined up and ensuring its slotted fully and securely into place
3. Insert the seat section lining up any stickers and ensuring it slots into place
4. Place the remaining arm section on top, lining up the holes and tap securely & fully into place.
5. Insert 3 bolts into place and hand tighten
6. Carefully rotate the chair onto its other side and insert the final 3 bolts – You may need help at this point
7. Stand the chair on its feet (Make sure the parts are still securely in place).and fully tighten all 6 bolts using the Allen Wrench

