

Oceanic Teak Furniture

Southampton Deep Seat Sofa Assembly

There are just 4 parts – Seat / Back / 2 x Arms (Left & Right) Plus 6 Brass Bolts & 1 Allen Wrench

Tools required – Wooden or Rubber Mallet

You will see there are coded stickers on the parts, make sure you align the relevant stickers to ensure the furniture is assembled correctly.

You may need to use a wooden or rubber mallet to tap the sections into place and ensure they are slotted together securely.

1. Lay one arm section flat on its side with the holes facing up.
2. Insert the seat section making sure any stickers are correctly lined up and ensuring the seat is slotted fully & securely into place.
3. Insert the back section, making sure any stickers are correctly lined up and ensure the back is slotted fully & securely into place.
4. Place the remaining arm section on top, lining up the holes and tap securely & fully into place.
5. Carefully rotate the seat and stand onto its legs – You may need help at this point – Make sure the parts are still securely in place.
6. Insert the brass bolts into the relevant holes on each side and hand tighten, then using the Allen wrench fully tighten each bolt.

